

PenPaper Note Tips

Introduction

Use this App to create your notes, memos, ideas, sketches, handwriting and drawings.

- Easily organizing, editing and viewing your book files.
- Page thumbnails function.
- Importing the photos or taking photos into a page.
- Exported as PDF and Image file.
- Sharing your handwriting or sketches in Community or Communication Apps.

Fine, precise and perfect pressure sensitive performance

You can use your finger(s) to write, draw or operate all functions in this App.


Tip! To get very fine and precise, with the perfect pressure sensitive performance for your handwriting and drawing, we recommend you to have a **PenPaper (Digital Notepad for iPad / iPhone)**. Visit www.acecad.com.tw for more information.



The PenPaper digitally captures and sends everything you write or draw by using pressure sensitive, battery-free and digital pen with ink on ordinary paper to PenPaper Note App in real time via **Bluetooth**.

Your handwriting or drawing on the PenPaper is displayed in the App according to the options you select in the App, such as pen style, color and line width.

The Pen tools in the App support the digital inking pen of the PenPaper.

The Pen tools include the Pressure Sensitive Pen tool  , the Regular Pen tool  and the Pencil tool .



[Click to play the Video](#)



The tools in the Bookshelf

Tip! Tap a book file to select it.

The selected book file will be surrounded by the orange frame.



Add a new book file.



Copy a book file.



Paste a book file.




Delete the selected book file.



Configure the Categories and Background Style for the selected book file.



Share the selected book file as PDF.



Pair the App with PenPaper.

- When connected, the tool lights in blue color.
- When disconnected, the tool lights in gray color.



This App Tips.



This App Information.

The tools in the current digital page

Tip! Tap the selected book file or double-tap the unselected book file to open it.

The current digital page in this book file will be displayed on the screen.



Save the current book file and return to Bookshelf.



Undo.



Redo.



Pressure Sensitive Pen.
Tap again to select color and line width.



Regular Pen (non-pressure sensitive pen).
Tap again to select color and line width.



Pencil.
Tap again to select color and line width.



Highlighter.
Tap again to select color and line width.



Eraser.



Text box.



Use the onscreen keyboard.



Select the font, text size, text color and text box background color.



Import a photo or take a photo.
After using the photo, you can resize, move and rotate the photo.



Import a photo from photo library.



Take a photo from camera.



Select objects.
Tap an object to select it.
*** You can change color of, resize, copy, paste, delete, rotate and move the selected objects.



Rectangular select.
Drag a rectangle around only the objects which you want to include in your selection.



Lasso select.
Drag a circle around only the objects which you want to include in your selection.



Direct select.

Drag over the stroke(s) which you want to include in your selection. The selection cannot select photo and text box?



Share the current page as PDF or Image.



View the current book file without any editing function.



Connect the App with the paired PenPaper.

- When connected, the tool lights in blue color. You can use the PenPaper with the App.
 - When disconnected, the tool lights in gray color.
-



Battery level of the connected PenPaper.

When the icon changes from green to red in the App and the right red LED slowly flashes on the digital pad, it indicates the low battery. Please charge your PenPaper battery.

You still can use the PenPaper when you charge your PenPaper battery.



Previous page.



Open the page thumbnails.



Next page or add a new page.




Palm rest. (Unavailable in iPhone version)

Drag the tool up to have a palm rest area on the lower part of the screen to avoid unwanted marks from the palm to appear on the current digital page when you use finger to write or draw.

When you use the PenPaper to write or draw, the palm rest area will be closed automatically.

The tools in the thumbnails

Tip! After you tap the Page thumbnail tool  to open the page thumbnails, you can use the finger to swipe the page thumbnails.

Tip! Tap a digital page to select it as the current digital page.
The current digital page will be surrounded by the orange frame.



Move to.

The current digital page will then be moved to the page you designate.



Add a new digital page next to the current digital page and it becomes the current digital page.



Select and Unselect the page(s).

- When selected, the check box lights in blue color.
 - When unselected, the check box lights in gray color.
-



Share the selected page(s) as PDF or Image.



Copy the selected page(s).



Paste the copied page(s) next to the current digital page in this or another book file.



Delete the selected page(s).

Zoom in or out the current digital page

You can zoom in the current digital page for finer and more precise drawing or modification. Even though you zoom in the current digital page, the paper notepad within the writing area on the digital pad still corresponds directly to the current whole digital page.

Automatic Shutdown function of the PenPaper

If you have not use or put the digital pen on the digital pad within the previous 30 minutes, the PenPaper automatically shuts down.

The App supports the background execution with the PenPaper

When the App connect to the PenPaper, even though the App is in the background or your iPhone sleeps, the current digital page still can work with your PenPaper.

Trademark Information

ACECAD is a registered trademark of ACE CAD Enterprise Co., Ltd.

The Bluetooth word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by ACE CAD Enterprise Co., Ltd. (ACECAD) is under license.

Other trademarks and trade names are those of their respective owners.

Copyright Notice

©2018 ACE CAD Enterprise Co., Ltd. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), without the prior written permission of the publisher.
